


## OFF/IGNITION/PRE-HEAT/HEAT START




4 position switch, off/ignition/pre-heat/heat start.

- Ø 16mm panel hole
- Supplied with two keys
- Replaces Lucas 35327

PART NO.	DESCRIPTION	QTY
0-351-04	4 position switch	1
0-351-10	Replacement key	1

## OFF/ACCESSORY/IGNITION/PRE-HEAT/HEAT START




5 position switch, off/accessory/ignition/pre-heat/heat start.

- Ø 19mm panel hole
- Supplied with two keys
- Replaces Lucas 36614

PART NO.	DESCRIPTION	QTY
0-351-08	5 position switch	1
0-351-10	Replacement key	1

## START/OFF/PRE-HEAT/HEAT START



4 position switch, start/off/pre-heat/heat start.

- Ø 16mm panel hole
- Supplied with two keys
- Replaces Lucas 35630

PART NO.	DESCRIPTION	QTY
0-351-07	4 position switch	1
0-351-10	Replacement key	1