


OFF/IGNITION/PRE-HEAT/HEAT START




4 position switch, off/ignition/pre-heat/heat start.

- Ø 16mm panel hole
- Supplied with two keys
- Replaces Lucas 34228, 35670

PART NO.	DESCRIPTION	QTY
0-351-06	4 position switch	1
0-351-10	Replacement key	1

OFF/ACCESSORY/IGNITION/START



4 position switch, off/accessory/ignition/start.

- Ø 22mm panel hole
- Supplied with two universal keys

PART NO.	DESCRIPTION	QTY
0-351-05	4 position switch	1
0-351-09	Spare universal key	1
0-351-02	Connecting socket with terminals	1
0-351-90	Splash-proof key slot cover	1

OFF/ON



2 position switch, off/on.

- Ø 22mm panel hole
- Supplied with two universal keys

PART NO.	DESCRIPTION	QTY
0-351-01	2 position switch	1
0-351-09	Spare universal key	1
0-351-02	Connecting socket with terminals	1
0-351-90	Splash-proof key slot cover	1